




| Prepare Standards | Prepare Urine Samples |
|---|--|
| <p>1. Re-suspend Standards</p> <p>Add 1 mL of Uri-Standard Sample Diluent/Zero Standard to each standard and control to reconstitute. Vortex Well.</p>  | <p>1. Centrifuge Samples</p> <p>Thaw frozen samples immediately before testing. Add 1.4 mL of thawed sample to a Protein LoBind tube. Centrifuge samples at 2,000 x g for 5 minutes to pellet any precipitates.</p>  |
| <p>2. Run Affinity Capture & Extraction (ACE) Kit</p> <p>The standards are now ready to be run along with the samples in the ACE Kit.</p> | <p>2. Transfer Samples</p> <p>Transfer the sample supernatant to a new Protein LoBind tube and discard tube with pellet.</p>  |
| | <p>3. Run Affinity Capture & Extraction (ACE) Kit</p> <p>The samples are now ready to be run along with the standards in the ACE Kit.</p> |